



HAMMERL GMBH & CO. KG

ERZEUGUNG FEINSTER GEIGENLACKE SEIT 1988.

Instruction: JOHA® Imitor

JOHA® Imitor is used for the antiquing.

It is applied by means of a sponge or another object. One dabs it on the places where the varnish is to be removed.

JOHA® Imitor should be left on the varnish for approximately five minutes and then be removed completely with a wet cloth or else all the varnish will be damaged. If one merely wants to achieve a coloring effect, JOHA® Imitor is applied to the varnish. If the instrument is intended to look somewhat "the worse wear", JOHA® Imitor should be applied to the finishing varnish. However, this results in rough patches. Here, too, JOHA® Imitor must be removed completely with plenty of water.